

MODELS COVERED:

GA- 01



GATE ACE®
DON'T GAMBLE WITH YOUR GATE

For assistance please contact Gate Ace LLC

Customer Service
info@thegateace.com
thegateace.com

DATE: Jan 2025

REVISION : 01

GATE ACE

CAUTION

KEEP VEHICLES AND LIVESTOCK CLEAR
DAMAGE MAY OCCUR IF CONTACT IS MADE

General Guidelines

- Please read the following instruction carefully and use the product accordingly.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.


Notes

- Please assemble this item strictly according to each step in the instructions.
- During assembly, first loosely fit all components then tighten the when instructed.
- Keep the product away from corrosive chemicals to prevent damage to the surfaces.
- Periodically inspect and tighten the nuts/bolts if necessary.

Warnings

- During assembly, keep all small parts out of the reach of children. It may be fatal if swallowed or inhaled.
- Children are not allowed to climb on the product to avoid personal injury caused by the product tilting or tipping over.
- Please do not use the product if there is/are defective and/or missing parts, as this can result in damage or injury.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (film, plastic bags, foam, etc.) away from babies and children.
- The product should be assembled with the included hardware*

Tools Required



*post mounting hardware not included



All Package Components



Included Hardware



Assembled Overview



Assembled Overview



1

Loose fit your Gate Ace together to measure your install height and distance from your fence post.



2

Choose the correct mounting hardware for your post mounting application. Note that the holes use for mounting hardware are 3/8" in diameter.

Mark, Drill, and attach the Gate Ace post bracket, ensuring the bracket is straight and centered on your mounting post.

3



Place and attach the slide bracket to the post bracket using the included 3/8" x 1" length bolts, washers and nuts. Adjust the Slide Bracket to your desired length. Then tighten your slide bracket into place.

Recommend to apply thread locker

4



Attach the Ramp to the Slide Bracket so that the Ramp faces the closing direction of the gate, using the included 3/8" x 4" length bolts, nuts and washers.

Recommend to apply thread locker

5



Test and ensure that your Gate Ace and gate are now the appropriate height and distance from each other for the Gate Ace to be effective.

Make adjustments as needed

6



Enjoy your long lasting gate support provided by the



GATE ACE[®]
DON'T GAMBLE WITH YOUR GATE

CAUTION

KEEP VEHICLES AND LIVESTOCK CLEAR

DAMAGE MAY OCCUR IF CONTACT IS MADE